




USER'S MANUAL

F50


Buttons and Functions

This product permits one person to speak to countless people at the same time in a long-distance without interference. (Only the transmitter sends the signal to the receivers)



1


LCD Display



Operation Instruction

Step 1: Turn on transmitter/receiver

Long press Power On button [ON] for 3 seconds to turn on the transmitter/receiver, the signal, battery level, volume and channel icons will be shown on the LCD display (The signal icon appears only when the receiver and transmitter in the same channel).




2

Step 2: Insert microphone/earpiece

Insert the microphone to the MIC jack on the transmitter, and insert the earpiece to the Earpiece jack on the receiver.


Note: DO NOT insert Microphone/Earphone wrongly into charging port to avoid damage the charging pin inside.



Step 3: Adjust Volume

Press the Power Button [ON] when the VOL icon appears on the display, press the Up Button [UP] to turn up the volume, and press the Down Button [DOWN] to turn down the volume. There are 10 volume levels of the transmitter and receiver.


3



Step 4: Set the Channel By Manual

Press the Power Button [ON] when the CH icon appears on the display, press the Up Button [UP] or Down Button [DOWN] to select the channel that you need to use.

Note: It is the same way for the transmitter and receiver to set the channel.




4

Channel Synchronization

This is the faster way to set the channels for transmitter and receiver. You could synchronize the channel by operating the transmitter instead of changing the channel of the receivers one by one.

A, Press the Power Button [ON] on the transmitter, the CH icon will appear on the display
B, Press Up [UP] or Down [DOWN] button to select the channel that you want to use
C, Then long press the Up Button [UP] and observe the screen of the receiver, release the Up Button [UP] after the channel on the receiver is changed. Then channel synced successfully.

Note: When you set the channel synchronization, please make sure the receiver is turned on and within 5m from the transmitter.



5

Key Lock Function

Long press the Down Button [DOWN] for 3 seconds to lock/unlock keys

One-key Mute

Transmitter and receiver channel synchronization: If you need to quickly adjust all receiver speakers to mute, just operate the transmitter.

- 1. Press the [MUTE] button on the transmitter, the "CH" icon appears on the screen;
2. Press the [MUTE] button again, the "VOL" icon appears on the screen
3. Press and hold the [MUTE] button again and observe the screen of the transmitter. Release the button after "M" appears, and the one-key mute is successful.
4. Long press the [MUTE] button again to unmute.

6

3. Press and hold the [+] button again and observe the screen of the transmitter. After "MIC" flashes, release the button and the one-button shutdown is successful

Notice:

- 1. Turn off transmitter before charging. The battery icon flashes during charging, and it will stop flashing and shows full once completed charging.
2. Kindly handle it carefully and avoid falling it down.
3. Already controlled receivers' channel won't be changed by its neighbouring transmitters from other groups at any time at the same place by any operations.
4. DO NOT use the same channel at the same place and same time for different groups.
5. The best distance between microphone and mouth is 3cm to 4cm. 6. For simultaneous interpretation, it is suggested to use the channels with a bigger gap to prevent cross-frequency interference.

7

RF ENERGY EXPOSURE AND PRODUCT SAFETY GUIDE



Before using this radio, read this guide which contains important operating instructions for safe usage and RF energy awareness and control for compliance with applicable standards and regulations.

This radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. RF energy, which when used improperly, can cause biological damage.

All Reteless radios are designed, manufactured, and tested to ensure they meet government-established RF exposure levels. In addition, manufacturers also recommend specific operating instructions to users of the radios. These instructions are important because they inform users about RF energy exposure and provide simple procedures on how to control it. Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits: http://www.who.int/en/

Local Government Regulations

When radios are used as a consequence of employment, the Local Government Regulations requires users to be fully aware of and able to control their exposure to meet occupational requirements. Exposure awareness can be facilitated by the use of a product label directing users to specific user

8

awareness information. Your Reteless radio has a RF Exposure Product Label. Also, your Reteless user manual, or separate safety booklet includes information and operating instructions required to control your RF exposure and to satisfy compliance requirements.

Radio License (if appropriate)

Governments keep the radios in classification, business radios operate on radio frequencies that are regulated by the local radio management departments (FCC, ISED, OFCOM, ANFR, BFTK, Bundesnetzagentur...). To transmit on these frequencies, you are required to have a license issued by them. The detailed classification and the use of your radios, please contact the local government radio management departments. Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

Unauthorized modification and adjustment

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority granted by the local government radio management departments to operate this radio and should not be made. To comply with the corresponding requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services.

9

Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the local government radio management departments equipment authorization for this radio could violate the rules.

FCC Requirements:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit

10

different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.

CE Requirements:

(Simple EU declaration of conformity) Henan Eshow Electronic Commerce Co., Ltd declares that the radio equipment type is in compliance with the essential requirements and other relevant provisions of RED Directive 2014/53/EU and the ROHS Directive 2011/65/EU and the WEEE Directive 2012/19/EU.

Disposal

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.

IC Requirements:

Licence-exempt radio apparatus This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
(2) This device must accept any interference,

11

including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Information

DO NOT operate the radio without a proper antenna attached, as this may damage the radio and may also cause you to exceed RF exposure limits. A proper antenna is the antenna supplied with this radio by the manufacturer or an antenna specifically authorized by the manufacturer for use with this radio, and the antenna gain shall not exceed the specified gain by the manufacturer declared. DO NOT transmit for more than 50% of total radio use time, more than 50% of the time can cause RF exposure compliance requirements to be exceeded. During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so. The device complies with RF specifications when the device used at 5mm from your body. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. DO NOT operate the transmitter in areas that are

12

sensitive to electromagnetic radiation such as hospitals, aircraft, and blasting sites.

Avoid Choking Hazard



Small Parts. Not for children under 3 years.

Protect your hearing:



- Use the lowest volume necessary to do your job.
Turn up the volume only if you are in noisy surroundings.
Turn down the volume before adding headset or earpiece.
Limit the amount of time you use headsets or earpieces at high volume.
When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear.
Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.
Note: Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.

13

Avoid Burns



Antennas Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a minor burn can result.

Batteries (If appropriate)

When the conductive material such as jewelry, keys or chains touch exposed terminals of the batteries, may complete an electrical circuit (short circuit the battery) and become hot to cause bodily injury such as burns. Exercise care in handling any battery, particularly when placing it inside a pocket, purse or other container with metal objects. Long transmission When the transceiver is used for long transmissions, the radiator and chassis will become hot.

Safety Operation



Forbid Do not use charger outdoors or in moist environments, use only in dry locations/conditions. Do not disassemble the charger, that may result in risk of electrical shock or fire. Do not operate the charger if it has been broken or damaged in any way. Do not place a portable radio in the area

14

over an air bag or in the air bag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the air bag inflates. To reduce risk Pull by the plug rather than the cord when disconnecting the charger. Unplug the charger from the AC outlet before attempting any maintenance or cleaning. Contact Reteless for assistance regarding repairs and service. The adapter shall be installed near the equipment and shall be easily accessible. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions. Adapter shall be installed near the equipment and shall be easily accessible. The plug considered as disconnect device of adapter. The operating temperature of the EUT can't exceed the specified range.

Approved Accessories



This radio meets the RF exposure guidelines when used with the Reteless accessories supplied or designated for the product. Use of other accessories may not ensure compliance with the RF exposure guidelines and may violate regulations.

15

Guarantee

Model Number: _____
Serial Number: _____
Purchasing Date: _____
Dealer: _____ Telephone: _____
User's Name: _____ Telephone: _____
Country: _____ Address: _____
Post Code: _____ Email: _____

Remarks:

- 1. This guarantee card should be kept by the user, no replacement if lost.
2. Most new products carry a two-year manufacturer's warranty from the date of purchase.
3. The user can get warranty and after-sales service as below:
- Contact the seller where you buy.
- Products Repaired by Our Local Repair Center
4. For warranty service, you will need to provide a receipt proof of purchase from the actual seller for verification

Exclusions from Warranty Coverage:

- 1. To any product damaged by accident.
2. In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs.
3. If the serial number has been altered, defaced, or removed.



Quanzhou Chierda Electronic Telecom Co., Ltd.
Add : No.8,Zi'an Road, Jiangnan High-tech Industrial Zone, Licheng District, Quanzhou, Fujian, China
www.chierda.com

10

11

12

13

14

15

9